

On Customer Site

Visit Report

Reference :

Commande BSTe France : SERV220530DTRRev.1		Commande BSTe : E1218	
Customer :	Amcor Flexibles Monceau	System :	iPQ Check Pro
Customer Contact :	Mme Audrey Klepper	SN / WA :	ASO074691 / WA0021471
Customer Order number :	CDE AGEPA LBE 20216125	Machine Nickname :	H5 - Recto

Visit Purpose :

Mechanical Preparation	☐	Installation	☐	Start-up	☐
Maintenance	☒	Under Contract	☐	Out of Contract	☒
Troubleshoot	☐	Under Warranty	☐	Out of Warranty	☐
Instruction	☒ Yes				
	☐ No				

	21/06/2022					
Travel To	0.5					
Start Time	8h00					
Lunch Time	1					
End Time	13h00					
Travel From	0					

Details	Maintenance Préventive du système iPQ Check Pro sur presse Rotopak 3000-3S. Mise à jour sur version Release (13/05/2022). Instruction opérateurs.
---------	---

Purpose of the visit completed : Yes ☒ No ☐

Need a new visit : Yes ☐ No ☒

On Customer Site

Maintenance Checklist for iPQ systems

Available supporting documents :

- iPQ-Center Setup Instruction
- iPQ-Center Maintenance routines
- WSC-Camera Maintenance routine
- LED illumination maintenance routine

Customer name and place : [Amcor Flexibles Monceau, Rue des Piges, 176 – 6031, Monceau – Belgique](#)

Contact person at customer : [Mrs Audrey Klepper \(CI & Process Manager\) / +32 494 574 625](#)

Customer Mail & Mobile/Landline : Audrey.klepper@amcor.com

System Type : [iPQ Check Pro](#)

WA/ASO : [WA0021470 / ASO074690](#)

Machine Manufacturer/Model/Nickname : [Rotomec/Rotopak 3000-3S/H5 Recto](#)

Date : [24/06/2022](#)

Name : [Arnaud Darcel & Richard Relin](#)

Comments :

Signatures :



Audrey Klepper 2022-06-24T11:58:09+02:00

BST eltromat FSE

Customer

On Customer Site

Prior to a Preventive Maintenance :

Check for system affecting modification reports and software releases.

Check for iPQ-Spectral sensor replace date.

Check with customer about problems and demands.

OK/NOK/NA

1. Replace filters of cabinets, check fan function.

☒ ☐ ☐

2. Visual check of system basic hardware condition :

OK/NOK/NA

- Check if all screws are in position and tightened.
- Check cables for damages and correct fit in cable trunks.
- Check if all connectors are tightened.

☒ ☐ ☐

☒ ☐ ☐

☒ ☐ ☐

3. Check image quality of screens with test pattern :

OK/NOK/NA

- Load test pattern from screen supplier on computer and display on all screens.
- Check for color quality, pixel defects, contrast, brightness.
- Recalibrate touch screen if necessary.

☒ ☐ ☐

☒ ☐ ☐

☐ ☒ ☐

4. Traverse and WSC-Camera according to separate instruction :

OK/NOK/NA

- Replace flash bulbs for main flash.
- Clean glasses in front of main flash.
- Change filters, check fan function.
- Clean lens from dust.
- Clean shadow reducing backplate.
- Check flash bulb in lacquer (Cold Seal) flash.
- Clean half mirrored glass in lacquer flash.
- Check ZIF function with buttons on WSC Control Board.
- Visual check and cleaning of traverse bars.

☐ ☐ ☒

☐ ☐ ☒

☐ ☐ ☒

☐ ☐ ☒

☐ ☐ ☒

☐ ☐ ☒

☐ ☐ ☒

☐ ☐ ☒

☐ ☐ ☒

On Customer Site

5. Check power flash or homogeneous BackPlate :

OK/NOK/NA

- Check function of flash bulbs according to instruction.
- Clean surface of white plate.
- Visual check and cleaning of traverse bars.

☐ ☐ ☒
☐ ☐ ☒
☐ ☐ ☒

6. Alarm status indicator :

OK/NOK/NA

- Check function of light bulbs in green, yellow and red.
- Check function of acoustic alarm.

☒ ☐ ☐
☒ ☐ ☐

7. Verify the web way in front of line cameras and under measurement wheel :

OK/NOK/NA

- There must be no waves on the web.
- The rollers must be smooth, not (max. slightly) spiraled. (iPQ-Check, sis,icm,bc).
- The guide rollers must rotate with the web speed.
- The measuring wheel must be mounted on a roller wrapped $\geq 90^\circ$ material.
- The line camera must be mounted according to project drawing.
- Web guiding unit in machine must be in operation.

☒ ☐ ☐
☒ ☐ ☐
☒ ☐ ☐
☒ ☐ ☐
☒ ☐ ☐
☒ ☐ ☐

8. Line ship cameras and illumination LED function and image quality :

OK/NOK/NA

- Clean internal mirrors and camera lenses with mirror cleaner.
- Clean LED front illumination and possible LED backlight with window cleaner.
- Verify mechanical mounting of components, special the position of LED backlight to front illumination unit.
- Check LEDs function by sunglasses or welding glasses.
- Change filters and check fans on function.
- Check / proceed the mechanical alignment.
- Check / proceed a white alignment.
- Check / proceed a shading.

☒ ☐ ☐
☒ ☐ ☐
☒ ☐ ☐
☒ ☐ ☐
☒ ☐ ☐
☐ ☒ ☐
☒ ☐ ☐
☒ ☐ ☐

On Customer Site

9. Check measurement wheel :

OK/NOK/NA

- Mounted according to latest mechanical drawing. ☒ ☐ ☐
- Pressure according to iPQ-Check maintenance manual. (10-15N) ☒ ☐ ☐
- No dirt or damages on rubber surface. ☒ ☐ ☐
- Smooth running. ☒ ☐ ☐
- Running on the web. ☒ ☐ ☐
- Not too far from line camera unit (≤ 1 meter). ☒ ☐ ☐
- Rollers not or only slightly spiraled. ☒ ☐ ☐

OK/NOK/NA

10. Exchange the UPS battery according to iPQ-Check maintenance.

☒ ☐ ☐

- Model : [EL1200USBIEC](#) Date : [2021](#)

11. Check for useful software update with release letter : (*)

OK/NOK/NA

- Update to latest released software version IF system is affected from bug fixes and/or new functions and features. ☒ ☐ ☐
- Check if an update of communication Workflow components is also necessary. ☐ ☒ ☐

12. Check Spectral color measurement :

OK/NOK/NA

- Check sensor front, sensor flashes and reference tiles for dust and contamination. ☐ ☐ ☒
- Proceed an alignment of sensor to backing by SUAT-tool. ☐ ☐ ☒
- Proceed an alignment of a possible backing wheel by SUAT-tool. ☐ ☐ ☒
- Check and clean backing from contamination. ☐ ☐ ☒
- Check if sensor can reach its manual calibration and parking position. ☐ ☐ ☒
- Check backing wheel functions : spin, air pressure, (parallel) position to web. ☐ ☐ ☒

On Customer Site

13. Check function and performance of the system :

OK/NOK/NA

- Performance of 100% print defect detection. ☒ ☐ ☐
- System performance at splice situations. ☒ ☐ ☐
- System performance after "out of print" situations. ☒ ☐ ☐
- System performance close to max. iPQ check system speed. ☒ ☐ ☐
- Check function/performance of additional software options like barcode, color Monitoring, Smartregister, etc. ☐ ☐ ☒
- Check remote service function with BST eltromat RS. (**) ☐ ☒ ☐
- Teamviewer Version check and upgrade (v15) : ☒ ☐ ☐
- Check availability of system in customer network for snapshot gallery, pdf-upload And WorkFlow applications. ☐ ☒ ☐

14. Give an instruction and production guiding for system operators.

OK/NOK/NA

- Explain new functions from software upgrade ☒ ☐ ☐
- Proceed a practice training at machine about all basic functions. ☒ ☐ ☐
- Explain special functions more detailed on operators request. ☒ ☐ ☐
- Guide the production and watch how operators work with the system to give hints for a better operation. ☒ ☐ ☐

15. Backup for customer :

OK/NOK/NA

- *Preconditions : above points are checked and okay* ☒ ☐ ☐
- Backup HardDisk or Image-PC exist from current Base Image -PC. ☒ ☐ ☐
- If NOK on previous point, make a new Image-PC or Backup HDD. ☒ ☐ ☐
- Write date and WA/ASO number on Backup HardDisk or Image-PC file name and give a copy to the customer. ☒ ☐ ☐

OK/NOK/NA

16. Make a backup for our own service purpose and put this on our server. (***)

☒ ☐ ☐

On Customer Site

Technical datas

Computer name : [21471iPQ-Center1-1](#)Computer description : [iPQ-Center,WA21471](#)Total Physical Memory : [48 GB](#)Free Space in C Drive (System) : [46 GB](#)Free Space in D Drive (Data) : [96.2 GB](#)Free Space in E Drive (Log) : [48.6 GB](#)Free Space in F Drive (Protocol) : [1.78 TB](#)Screen Resolution 1 : [1920X1080](#)Screen Resolution 2 : [1920X1080](#)Camera Type : [DALSA P4 70Hz – Qty : 3](#)Computer Model / Image : [beg-BKA-BSTE02](#)Date : [2021](#)Global Version : Current : [2.16.1](#)New : [2.17.7](#)TCU.x : Current : [1.12](#)New : [1.12](#)

WSX_3xx/WSC_4xx : Current :

New :

PPS.3 : Current :

New :

ILI-CTRL : Current : [1.4.3](#)New : [1.4.3](#)**Remote Maintenance (Teamviewer)**IP address : [10.74.46.72](#)Subnet mask : [255.255.255.0](#)Default gateway : [10.74.46.1](#)

Preferred DNS server :

Alternate DNS server :

On Customer Site

Remote Access (Snapshot gallery, pdf upload, WF applications)

IP address :

Subnet mask :

Default gateway :

Preferred DNS server :

Alternate DNS server :

Teamviewer : [1 097 313 623 / v15](https://www.teamviewer.com/fr)

- Dcf and pdfx folder
- Windows Credentials
- iPQ-xxxxxx_bak_date_time.zip file generated from sysconfig.py
- MmxlpMap file in mmx folder for Check systems (Overlapping)
- Screenshot from Application settings
- Screenshot from visconfig.py (Mmx + Srb + Image)

OK/NOK/NA



On Customer Site

Notes
