

Visit Report

Reference :

Commande BSTe France : CM1912025		Call / PM number : PM348	
Customer :	CPC Cotentin	System :	iPQ Center
Customer Contact :	M. Emmanuel Cornu	SN / WA :	ASO045079 / WA20214
Customer Order number :		Machine Nickname :	Bobst/ RS6003

Visit Purpose :

Mechanical Preparation	☐	Installation	☐	Start-up	☐
Maintenance	☒	Under Contract	☒	Out of Contract	☐
Troubleshoot	☐	Under Warranty	☐	Out of Warranty	☐
Instruction	☐ Yes				
	☒ No				

	18 / 07 / 2022	/ /	/ /	/ /	/ /	/ /
Travel To	5.5					
Start Time	14h30					
Lunch Time	0					
End Time	19h00					
Travel From	0.5					

Details	Maintenance préventive du système iPQ Center sur presse RS6003 suivant check list. Mesure distance cello vérification des distances. Réinstallation système et backup.
---------	--

Purpose of the visit completed : Yes ☒ No ☐

Need a new visit : Yes ☐ No ☒

Maintenance Checklist for iPQ systems

Available supporting documents :

- iPQ-Center Setup Instruction
- iPQ-Center Maintenance routines
- WSC-Camera Maintenance routine
- LED illumination maintenance routine

Customer name and place : [CPC Cotentin / Chemin de la Canurie, 50250 La Haye-du-Puits](#)

Contact person at customer / Title : [M. Emmanuel Cornu \(Responsable Maintenance & Travaux neufs\)](#)

Customer Mail & Mobile/Landline : e.cornu-cotentin@cpcpackaging.com / +33 2 33 07 33 11

System Type : [iPQ Center](#)

WA/ASO : [WA20214 / ASO045079](#)

Machine Manufacturer/Model/Nickname : [Bobst / RS 6003 CHS / Bobst](#)

Date : [19/07/2022](#)

Name : [Richard Relin](#)

Comments :

Signatures :



Richard Relin 2022-07-19T13:32:13+02:00



Emmanuel Cornu 2022-07-19T13:31:57+02:00

BST eltromat FSE

Customer

Prior to a Preventive Maintenance :

Check for system affecting modification reports and software releases.

Check for iPQ-Spectral sensor replace date.

Check with customer about problems and demands.

OK/NOK/NA

1. Replace filters of cabinets, check fan function.

☒ ☐ ☐

2. Visual check of system basic hardware condition :

OK/NOK/NA

- Check if all screws are in position and tightened.
- Check cables for damages and correct fit in cable trunks.
- Check if all connectors are tightened.

☒ ☐ ☐

☒ ☐ ☐

☒ ☐ ☐

3. Check image quality of screens with test pattern :

OK/NOK/NA

- Load test pattern from screen supplier on computer and display on all screens.
- Check for color quality, pixel defects, contrast, brightness.
- Recalibrate touch screen if necessary.

☐ ☒ ☐

☒ ☐ ☐

☐ ☒ ☐

4. Traverse and WSC-Camera according to separate instruction :

OK/NOK/NA

- Replace flash bulbs for main flash.
- Clean glasses in front of main flash.
- Change filters, check fan function.
- Clean lens from dust.
- Clean shadow reducing backplate.
- Check flash bulb in lacquer (Cold Seal) flash.
- Clean half mirrored glass in lacquer flash.
- Check ZIF function with buttons on WSC Control Board.
- Visual check and cleaning of traverse bars.

☐ ☒ ☐

☒ ☐ ☐

☒ ☐ ☐

☒ ☐ ☐

☒ ☐ ☐

☐ ☐ ☒

☐ ☐ ☒

☒ ☐ ☐

☒ ☐ ☐

5. Check power flash or homogeneous BackPlate :

OK/NOK/NA

- Check function of flash bulbs according to instruction. ☒ ☐ ☐
- Clean surface of white plate. ☒ ☐ ☐
- Visual check and cleaning of traverse bars. ☒ ☐ ☐

6. Alarm status indicator :

OK/NOK/NA

- Check function of light bulbs in green, yellow and red. ☒ ☐ ☐
- Check function of acoustic alarm. ☒ ☐ ☐

7. Verify the web way in front of line cameras and under measurement wheel :

OK/NOK/NA

- There must be no waves on the web. ☐ ☒ ☐
- The rollers must be smooth, not (max. slightly) spiraled. (iPQ-Check, sis,icm,bc). ☐ ☒ ☐
- The guide rollers must rotate with the web speed. ☒ ☐ ☐
- The measuring wheel must be mounted on a roller wrapped $\geq 90^\circ$ material. ☒ ☐ ☐
- The line camera must be mounted according to project drawing. ☒ ☐ ☐
- Web guiding unit in machine must be in operation. ☒ ☐ ☐

8. Line ship cameras and illumination LED function and image quality :

OK/NOK/NA

- Clean internal mirrors and camera lenses with mirror cleaner. ☒ ☐ ☐
- Clean LED front illumination and possible LED backlight with window cleaner. ☒ ☐ ☐
- Verify mechanical mounting of components, special the position of LED backlight to front illumination unit. ☒ ☐ ☐
- Check LEDs function by sunglasses or welding glasses. ☒ ☐ ☐
- Change filters and check fans on function. ☒ ☐ ☐
- Check / proceed the mechanical alignment. ☒ ☐ ☐
- Check / proceed a white alignment. ☒ ☐ ☐
- Check / proceed a shading. ☐ ☒ ☐

9. Check measurement wheel :

OK/NOK/NA

- Mounted according to latest mechanical drawing. ☒ ☐ ☐
- Pressure according to iPQ-Check maintenance manual. (10-15N) ☒ ☐ ☐
- No dirt or damages on rubber surface. ☒ ☐ ☐
- Smooth running. ☒ ☐ ☐
- Running on the web. ☒ ☐ ☐
- Not too far from line camera unit (≤ 1 meter). ☒ ☐ ☐
- Rollers not or only slightly spiraled. ☒ ☐ ☐

OK/NOK/NA

10. Exchange the UPS battery according to iPQ-Check maintenance.
☐ ☒ ☐

- Model : **ELIPSE ECO 1200** Date : **2018**

11. Check for useful software update with release letter : (*)

OK/NOK/NA

- Update to latest released software version IF system is affected from bug fixes and/or new functions and features. ☒ ☐ ☐
- Check if an update of communication Workflow components is also necessary. ☐ ☒ ☐

12. Check function and performance of the system :

OK/NOK/NA

- Performance of 100% print defect detection. ☒ ☐ ☐
- System performance at splice situations. ☒ ☐ ☐
- System performance after "out of print" situations. ☒ ☐ ☐
- System performance close to max. iPQ check system speed. ☒ ☐ ☐
- Check function/performance of additional software options like barcode, color Monitoring, Smartregister, etc. ☒ ☐ ☐
- Check remote service function with BST eltromat RS. (**) ☒ ☐ ☐
- Teamviewer Version check and upgrade (v12) : ☒ ☐ ☐
- Check availability of system in customer network for snapshot gallery, pdf-upload And WorkFlow applications. ☒ ☐ ☐

13. Backup for customer :

OK/NOK/NA

- *Preconditions : above points are checked and okay* ☒ ☐ ☐
- Backup HardDisk or Image-PC exist from current Base Image -PC. ☒ ☐ ☐
- If NOK on previous point, make a new Image-PC or Backup HDD. ☒ ☐ ☐
- Write date and WA/ASO number on Backup HardDisk or Image-PC file name and give a copy to the customer. ☒ ☐ ☐

OK/NOK/NA

Make a backup for our own service purpose and put this on our server. (*)**☒ ☐ ☐

Technical datas

Main Power 230V Input : [229V](#)

Computer name : [20214iPQ-Center1-1](#)

Computer description : [iPQ Center, WA20214](#)

Total Physical Memory : [48 GB](#)

Free Space in C Drive (System) : [48.5 GB](#)

Free Space in D Drive (Data) : [95.5 GB](#)

Free Space in E Drive (Log) : [48.6 GB](#)

Free Space in F Drive (Protocol) : [1.63 TB](#)

Screen Resolution 1 : [1920x1080](#)

Screen Resolution 2 : [1920x1080](#)

Screen Resolution 3 : [1920x1080](#)

Screen Resolution 4 :

Camera Type : [2 X DALSA-P4-70KHz](#)

Computer Model / Image : [IPC-BKA-BSTE02](#)

Date : [2018W10](#)

UPS Catalog Nb : [EL1200USBIEC](#)

(*)	Global Version :	Current : 2.17.2	New :
	TCU.x :	Current : 1.12	New :
	WSX_3xx/WSC_4xx :	Current : 1.9.4	New :
	PPS.3 :	Current : 2.2	New :
	ILI-CTRL :	Current : 1.4.3	New :

(**) **Remote Maintenance (Teamviewer)**

IP address : [10.50.21.14](#)

Subnet mask : [255.255.255.0](#)

Default gateway : [10.50.21.1](#)

Preferred DNS server : [10.50.21.1](#)

Alternate DNS server :

Remote Access (Snapshot gallery, pdf upload, WF applications)

IP address :

Subnet mask :

Default gateway :

Preferred DNS server :

Alternate DNS server :

Teamviewer ID : [1 035 997 951 / v12](#)

OK/NOK/NA

(***)	- Dcf and pdfx folder	☐	☒	☐
	- Windows Credentials	☐	☒	☐
	- iPQ-xxxxxx_bak_date_time.zip file generated from sysconfig.py	☒	☐	☐
	- MmxlpmMap file in mmx folder for Check systems (Overlapping)	☒	☐	☐
	- Screenshot from Application settings	☐	☒	☐
	- Screenshot from visconfig.py (Mmx + Srb + Image)	☐	☒	☐

Parts replaced during Preventive Maintenance :

1 -

2 -

Parts suggested to replace during the next Maintenance :

1 – [Plaque backlight](#)

3- [Measurement wheel](#)

2 - [8 Bulbs](#)

4-

Part need to be replaced as soon as possible :

1 -

2 -

Notes

Roue codeuse a changer:



