

On Customer Site

Visit Report

Reference :

Commande BSTe France : CM2112043		Commande BSTe : PM446	
Customer :	Socoplan (Arcade Beauty)	System :	iPQ Center
Customer Contact :	M. Franck Bourdon	SN / WA :	ASO076651 / WA0021547
Customer Order number :		Machine Nickname :	DCM 3 – CI12284

Visit Purpose :

Mechanical Preparation	☐	Installation	☐	Start-up	☐
Maintenance	☒	Under Contract	☒	Out of Contract	☐
Troubleshoot	☐	Under Warranty	☐	Out of Warranty	☐
Instruction	☐ Yes				
	☒ No				

	21/03/2023	22/03/2023				
Travel To	2	0.5				
Start Time		8h30				
Lunch Time		0				
End Time		14h00				
Travel From		4				

Details	Maintenance Préventive – Mise à jour v2.17.8 vers v2.17.9. Calibration Whitefader/Iri/Zoom.
---------	---

Purpose of the visit completed : Yes ☒ No ☐

Need a new visit : Yes ☐ No ☒

On Customer Site

Customer name and place : [Socoplan \(Arcade Beauty\)](#), 12 All. De Dissé - 79600, Airvault – France

Contact person at customer : [M. Franck Bourdon](#)

Customer Mail & Mobile/Landline : f.bourdon@arcadebeauty.com / +33 6 07 48 31 95 / +33 5 49 64 95 01

System Type : [iPQ Center](#)

WA/ASO : [WA0021547](#) / [ASO076651](#)

Machine Manufacturer/Model/Nickname : [DCM](#) / [BIVA 2–680-9C](#) / [DCM 3](#)


Date : [22/03/2023](#)

Name : [Arnaud Darcel](#)

Comments :

Signatures :

Arnaud Darcel 2023-03-22T12:44:43+01:00



Franck Bourdon 2023-03-22T12:44:25+01:00

BST eltromat FSE

Customer

On Customer Site

Prior to a Preventive Maintenance :

Check for system affecting modification reports and software releases.

Check for iPQ-Spectral sensor replace date.

Check with customer about problems and demands.

OK/NOK/NA

1. Replace filters of cabinets, check fan function.

☒ ☐ ☐

2. Visual check of system basic hardware condition :

OK/NOK/NA

- Check if all screws are in position and tightened.
- Check cables for damages and correct fit in cable trunks.
- Check if all connectors are tightened.

☒ ☐ ☐

☒ ☐ ☐

☒ ☐ ☐

3. Check image quality of screens with test pattern :

OK/NOK/NA

- Load test pattern from screen supplier on computer and display on all screens.
- Check for color quality, pixel defects, contrast, brightness.
- Recalibrate touch screen if necessary.

☒ ☐ ☐

☒ ☐ ☐

☐ ☒ ☐

4. Traverse and WSC-Camera according to separate instruction :

OK/NOK/NA

- Replace flash bulbs for main flash.
- Clean glasses in front of main flash.
- Change filters, check fan function.
- Clean lens from dust.
- Clean shadow reducing backplate.
- Check flash bulb in lacquer (Cold Seal) flash.
- Clean half mirrored glass in lacquer flash.
- Check ZIF function with buttons on WSC Control Board.
- Visual check and cleaning of traverse bars.

☐ ☒ ☐

☒ ☐ ☐

☒ ☐ ☐

☒ ☐ ☐

☒ ☐ ☐

☐ ☐ ☒

☐ ☐ ☒

☒ ☐ ☐

☒ ☐ ☐

On Customer Site

5. Check power flash or homogeneous BackPlate :

OK/NOK/NA

- Check function of flash bulbs according to instruction.
- Clean surface of white plate.
- Visual check and cleaning of traverse bars.

☐	☐	☒
☐	☐	☒
☐	☐	☒

6. Alarm status indicator :

OK/NOK/NA

- Check function of light bulbs in green, yellow and red.
- Check function of acoustic alarm.

☒	☐	☐
☒	☐	☐

7. Verify the web way in front of line cameras and under measurement wheel :

OK/NOK/NA

- There must be no waves on the web.
- The rollers must be smooth, not (max. slightly) spiraled. (iPQ-Check, sis,icm,bc).
- The guide rollers must rotate with the web speed.
- The measuring wheel must be mounted on a roller wrapped $\geq 90^\circ$ material.
- The line camera must be mounted according to project drawing.
- Web guiding unit in machine must be in operation.

☒	☐	☐
☒	☐	☐
☒	☐	☐
☒	☐	☐
☒	☐	☐
☒	☐	☐

8. Line ship cameras and illumination LED function and image quality :

OK/NOK/NA

- Clean internal mirrors and camera lenses with mirror cleaner.
- Clean LED front illumination and possible LED backlight with window cleaner.
- Verify mechanical mounting of components, special the position of LED backlight to front illumination unit.
- Check LEDs function by sunglasses or welding glasses.
- Change filters and check fans on function.
- Check / proceed the mechanical alignment.
- Check / proceed a white alignment.
- Check / proceed a shading.

☒	☐	☐
☒	☐	☐
☒	☐	☐
☒	☐	☐
☒	☐	☐
☐	☒	☐
☐	☒	☐
☐	☒	☐

On Customer Site

9. Check measurement wheel :

OK/NOK/NA

- Mounted according to latest mechanical drawing. ☒ ☐ ☐
- Pressure according to iPQ-Check maintenance manual. (10-15N) ☒ ☐ ☐
- No dirt or damages on rubber surface. ☒ ☐ ☐
- Smooth running. ☒ ☐ ☐
- Running on the web. ☒ ☐ ☐
- Not too far from line camera unit (≤ 1 meter). ☒ ☐ ☐
- Rollers not or only slightly spiraled. ☒ ☐ ☐

OK/NOK/NA

10. Exchange the UPS battery according to iPQ-Check maintenance.
☐ ☒ ☐

- Model : [EL1200USBIEC](#) Date : [2021](#)

11. Check for useful software update with release letter : (*)

OK/NOK/NA

- Update to latest released software version IF system is affected from bug fixes and/or new functions and features. ☒ ☐ ☐
- Check if an update of communication Workflow components is also necessary. ☐ ☒ ☐

12. Check function and performance of the system :

OK/NOK/NA

- Performance of 100% print defect detection. ☒ ☐ ☐
- System performance at splice situations. ☒ ☐ ☐
- System performance after "out of print" situations. ☒ ☐ ☐
- System performance close to max. iPQ check system speed. ☒ ☐ ☐
- Check function/performance of additional software options like barcode, color Monitoring, Smartregister, etc. ☒ ☐ ☐
- Check remote service function with BST eltromat RS. (**) ☒ ☐ ☐
- Teamviewer Version check and upgrade (v15) : ☒ ☐ ☐
- Check availability of system in customer network for snapshot gallery, pdf-upload ☐ ☒ ☐

On Customer Site

And WorkFlow applications.

13. Backup for customer :

- *Preconditions : above points are checked and okay*
- Backup HardDisk or Image-PC exist from current Base Image -PC.
- If NOK on previous point, make a new Image-PC or Backup HDD.
- Write date and WA/ASO number on Backup HardDisk or Image-PC file name and give a copy to the customer.

OK/NOK/NA

☒☐☐☒☐☐☒☐☐☐☒☐

OK/NOK/NA

Make a backup for our own service purpose and put this on our server. (*)**

☒☐☐

Parts replaced during Preventive Maintenance :

1 –

2 -

Parts suggested to replace during the next Maintenance :

1 – 8 Flash Bulbs

2 -

Part need to be replaced as soon as possible :

1 –

2 -

On Customer Site

Technical datas

Computer name : [21547IPQ-Center1-1](#)Computer description : [iPQ-Center, WA21547](#)Total Physical Memory : [64 GB](#)Free Space in C Drive (System) : [45.5 GB](#)Free Space in D Drive (Data) : [61.5 GB](#)Free Space in E Drive (Log) : [48.1 GB](#)Free Space in F Drive (Protocol) : [7.18 TB](#)Screen Resolution 1 : [1920x1080](#)Screen Resolution 2 : [1920x1080](#)Camera Type : [DALSA P4 40Hz – Qty : 1](#)Computer Model / Image : [beg-BKA-BSTE03](#)Date : [2021](#)Boot = [F12](#)Global Version : Current : [2.17.8](#)New : [2.17.9](#)TCU.x : Current : [1.12](#)New : [1.12](#)WSX_3xx/WSC_4xx : Current : [1.9.6](#)New : [1.9.6](#)PPS.3 : Current : [2.2](#)New : [2.2](#)ILI-CTRL : Current : [1.4.3](#)New : [1.4.3](#)**Remote Maintenance (Teamviewer)**IP address : [172.20.11.50](#)Subnet mask : [255.255.255.0](#)Default gateway : [172.20.11.254](#)Preferred DNS server : [172.20.20.10](#)Alternate DNS server : [10.217.3.10](#)

On Customer Site

Remote Access (Snapshot gallery, pdf upload, WF applications)

IP address :

Subnet mask :

Default gateway :

Preferred DNS server :

Alternate DNS server :

Teamviewer : [280 278 141 / v15](#)

- Dcf and pdfx folder
- Windows Credentials
- iPQ-xxxxxx_bak_date_time.zip file generated from sysconfig.py
- MmxlpmMap file in mmx folder for Check systems (Overlapping)
- Screenshot from Application settings
- Screenshot from visconfig.py (Mmx + Srb + Image)

OK/NOK/NA



On Customer Site

Notes
