

On Customer Site

Visit Report

Reference :

Commande BSTe France : CM2103037		Call / PM number : PM 247	
Customer :	Schur Flexibles Uni Roto	System :	Webvideo_star 2000
Customer Contact :	M. Thomas Tronchet	ASO / WA :	WA18482
Customer Order number :		Machine Nickname :	Roto 09

Visit Purpose :

Mechanical Preparation	☐	Installation	☐	Start-up	☐
Maintenance	☒	Under Contract	☒	Out of Contract	☐
Troubleshoot	☐	Under Warranty	☐	Out of Warranty	☐
Instruction	☐ Yes				
	☒ No				

	17 / 10 / 2021	/ /	/ /	/ /	/ /	/ /
Travel To	4h00					
Start Time	13h30					
Lunch Time	0.5					
End Time	14h30					
Travel From	0					

Details	Vérification de fonctionnemnt suivant la liste ci-dessous.
---------	--

Purpose of the visit completed : Yes ☒ No ☐

Need a new visit : Yes ☐ No ☒

On Customer Site

Maintenance Checklist for **wevideo_star 2000**

Available supporting documents :

- iPQ-Center Setup Instruction
- iPQ-Center Maintenance routines
- WSC-Camera Maintenance routine
- LED illumination maintenance routine

Customer name and place : [Schur Flexibles Uni Roto – 24 Hameau de la Neuville – 62127 Averdoingt - France](#)

Contact person at customer / Title : [M. Thomas Tronchet \(Maintenance Manager\)](#)

Customer Mail & Mobile/Landline : thomas.tronchet@schurflexibles.com / +33 7 64 41 95 75

System Type : [wevideo_star 2000](#)

WA/ASO : [WA18482](#)

Machine Manufacturer/Model/Nickname : [Bobst / Rotomec 4003 MP 1100-350-C / Roto 09](#)

Date : [18/10/2021](#)

Name : [Richard Relin](#)

Comments :

Signatures :



Richard Relin 2021-10-22T09:56:33+02:00

BST eltromat FSE



Customer

On Customer Site

Prior to a Preventive Maintenance :

Check for system affecting modification reports and software releases.

Check for iPQ-Spectral sensor replace date.

Check with customer about problems and demands.

1. Visual check of system basic hardware condition :

- Check if all screws are in position and tightened.
- Check cables for damages and correct fit in cable trunks.
- Check if all connectors are tightened.

OK/NOK/NA

OK/NOK/NA

☒ ☐ ☐

☒ ☐ ☐

☒ ☐ ☐

2. Check image quality of screens with test pattern :

- Load test pattern from screen supplier on computer and display on all screens.
- Check for color quality, pixel defects, contrast, brightness.
- Recalibrate touch screen if necessary.

OK/NOK/NA

☒ ☐ ☐

☒ ☐ ☐

☒ ☐ ☐

3. Traverse and WSC-Camera according to separate instruction :

- Replace flash bulbs for main flash.
- Clean glasses in front of main flash.
- Change filters, check fan function.
- Clean lens from dust.
- Clean shadow reducing backplate.
- Check flash bulb in lacquer (Cold Seal) flash.
- Clean half mirrored glass in lacquer flash.
- Check ZIF function with buttons on WSC Control Board.
- Visual check and cleaning of traverse bars.

OK/NOK/NA

☒ ☐ ☐

☒ ☐ ☐

☒ ☐ ☐

☒ ☐ ☐

☒ ☐ ☐

☐ ☐ ☒

☐ ☐ ☒

☐ ☒ ☐

☒ ☐ ☐

On Customer Site

4. Check power flash or homogeneous BackPlate :

OK/NOK/NA

- Check function of flash bulbs according to instruction. ☒ ☐ ☐
- Clean surface of white plate. ☒ ☐ ☐
- Visual check and cleaning of traverse bars. ☒ ☐ ☐

OK/NOK/NA

5. Exchange the UPS battery according to iPQ-Check maintenance.

☐ ☐ ☒

- Model : 3S 700 IES Date : 2013

6. Check for useful software update with release letter: (*)

OK/NOK/NA

- Update to latest released software version IF system is affected from bug fixes and/or new functions and features. ☒ ☐ ☐
- Check if an update of communication Workflow components is also necessary. ☐ ☐ ☒

7. Check function and performance of the system :

OK/NOK/NA

- Performance of 100% print defect detection. ☐ ☐ ☒
- System performance at splice situations. ☐ ☐ ☒
- System performance after "out of print" situations. ☐ ☐ ☒
- System performance close to max. iPQ check system speed. ☐ ☐ ☒
- Check function/performance of additional software options like barcode, color Monitoring, Smartregister, etc. ☐ ☐ ☒
- Check remote service function with BST eltromat RS. (**) ☒ ☐ ☐
- Teamviewer Version check and upgrade (v12) : ☒ ☐ ☐
- Check availability of system in customer network for snapshot gallery, pdf-upload And WorkFlow applications. ☐ ☐ ☒

8. Give an instruction and production guiding for system operators.

OK/NOK/NA

- Explain new functions from software upgrade ☐ ☒ ☐
- Proceed a practice training at machine about all basic functions. ☐ ☒ ☐

On Customer Site

- Explain special functions more detailed on operators request. ☐ ☒ ☐
- Guide the production and watch how operators work with the system to give hints for a better operation. ☐ ☒ ☐

9. Backup for customer :

OK/NOK/NA

- *Preconditions : above points are checked and okay* ☒ ☐ ☐
- Backup HardDisk or Image-PC exist from current Base Image -PC. ☐ ☒ ☐
- If NOK on previous point, make a new Image-PC or Backup HDD. ☒ ☐ ☐
- Write date and WA/ASO number on Backup HardDisk or Image-PC file name and give a copy to the customer. ☐ ☒ ☐

OK/NOK/NA

10. Make a backup for our own service purpose and put this on our server. (*)**☒ ☐ ☐

On Customer Site

Technical datas

Computer name : [18482](#)

Total Physical Memory : [4 GB](#)

Free Space in C Drive (System) : [190 GB](#)

Free Space in D Drive (Data) : [4 GB](#)

Free Space in E Drive (Log) : [XX.X GB](#)

Free Space in F Drive (Protocol) : [X.XX TB](#)

OS : [Windows 7 PRO](#)

Computer Model/ Image : [1.0.1](#)

(**) Remote Maintenance (Teamviewer)

IP address :

Subnet mask :

Default gateway :

Preferred DNS server :

Alternate DNS server :

Remote Access (Snapshot gallery, pdf upload, WF applications)

IP address :

Subnet mask :

Default gateway :

Preferred DNS server :

Alternate DNS server :

On Customer Site

	OK/NOK/NA
(**) - Dcf and pdfx folder	☐ ☒ ☐
- Windows Credentials	☐ ☒ ☐
- iPQ-xxxxxx_bak_date_time.zip file generated from sysconfig.py	☒ ☐ ☐
- MmxlpMap file in mmx folder for Check systems (Overlapping)	☐ ☒ ☐
- Screenshot from Application settings	☒ ☐ ☐
- Screenshot from visconfig.py (Mmx + Srb + Image)	☒ ☐ ☐



wevideo_star Systems Preventive Maintenance

On Customer Site

Notes