

On Customer Site

Visit Report

Reference :

Commande BSTe France : CM2103037		Call / PM number : PM 512	
Customer :	Schur Flexibles Uni Roto	System :	PS 5000
Customer Contact :	M. Aurelien Gervois	ASO / WA :	ASO075570
Customer Order number :		Machine Nickname :	BOBCAT

Visit Purpose :

Mechanical Preparation	☐	Installation	☐	Start-up	☐
Maintenance	☒	Under Contract	☒	Out of Contract	☐
Troubleshoot	☐	Under Warranty	☐	Out of Warranty	☐
Instruction	☐ Yes				
	☒ No				

	28 / 09 / 2023	/ /	/ /	/ /	/ /	/ /
Travel To	0					
Start Time	10h30					
Lunch Time	0					
End Time	11h00					
Travel From	0					

Details	Maintenance Préventive
---------	------------------------

Purpose of the visit completed : Yes ☒ No ☐

Need a new visit : Yes ☐ No ☒

On Customer Site

Maintenance Checklist for PS Systems

Available supporting documents :

- iPQ-Center Setup Instruction
- iPQ-Center Maintenance routines
- WSC-Camera Maintenance routine
- LED illumination maintenance routine

Customer name and place : [Schur Flexibles Uni Roto – 24 Hameau de la Neuville – 62127 Averdoingt - France](#)

Contact person at customer / Title : [M. Aurelin Gervois \(Maintenance \)](#)

Customer Mail & Mobile/Landline : Aurelien.gervois@schurflexibles.com / +33 6 02 03 59 57

System Type : [PS 5000](#)

WA/ASO : [ASO075570](#)

Machine Manufacturer/Model/Nickname : [/ BOBCAT](#)

Date : [28/09/2023](#)

Name : [Richard Relin](#)

Comments :

Signatures :



Richard Relin 2023-10-04T18:57:08+02:00



2023-09-28T17:37:18+02:00

BST eltromat FSE

Customer

On Customer Site

Prior to a Preventive Maintenance :

Check for system affecting modification reports and software releases.

Check for iPQ-Spectral sensor replace date.

Check with customer about problems and demands.

1. Digital Controller :

OK/NOK/NA

- Check fan function.

☒ ☐ ☐

- Replace or ~~clean~~ fan filter.

☒ ☐ ☐

2. Visual check of system basic hardware condition :

OK/NOK/NA

- Check if all screws are in position and tightened.

☒ ☐ ☐

- Check cables for damages and correct fit in cable trunks.

☒ ☐ ☐

- Check if all connectors are tightened.

☒ ☐ ☐

3. Check image quality of screens with test pattern :

OK/NOK/NA

- Load test pattern from screen supplier on computer and display on all screens.

☐ ☐ ☒

- Check for color quality, pixel defects, contrast, brightness.

☒ ☐ ☐

- White calibration (if the colors are not uniform)

☐ ☐ ☒

- Gray calibration (color control option)

☐ ☐ ☒

- Lens calibration (Register option)

☐ ☐ ☒

- Recalibrate touch screen if necessary.

☐ ☒ ☐

4. Traverse and Optic Head according to separate instruction :

OK/NOK/NA

- Replace flash bulbs / flash blocks.

☐ ☒ ☐

Last replacement date :

Screwed ☐

Welded ☒

- Clean glasses on flash units (Top/Bottom).

☒ ☐ ☐

- Lens glass cleaning.

☒ ☐ ☐

- Visual check and of traverse bars.

☒ ☐ ☐

On Customer Site

5. Check power flash or homogeneous BackPlate :

OK/NOK/NA

- Check function of flash bulbs.

☒☐☐

Result :

- ~~Clean~~/Check surface of BackPlate.

☒☐☐

Dimension :

6. Alarm status indicator :

OK/NOK/NA

- Check function of light bulbs in green, yellow and red.
- Check function of acoustic alarm.

☐☐☒☐☐☒**7. Check for useful software update with release letter : (*)**

OK/NOK/NA

- Update to latest released software version IF system is affected from bug fixes and/or new functions, features and developments.

☐☒☐**8. Give an instruction and production guiding for system operators.**

OK/NOK/NA

- Explain special functions more detailed on operators (On request).
- Guide the production and watch how operators work with the system to give hints for a better operation if necessary.

☐☒☐☐☒☐**9. Make a backup for our own service purpose and put this on our server.**

OK/NOK/NA

☐☒☐

On Customer Site

Technical datas

Computer name : [PS5000](#)

Computer description :

Screen Resolution 1 : [1280x1024](#)

Computer Type : [PD Controller PS5000](#)

(*) Global Version : Current : [1.4.5](#) New :

(**) **Remote Maintenance (Teamviewer)**

IP address :

Subnet mask :

Default gateway :

Preferred DNS server :

Alternate DNS server :

Teamviewer ID :

OK/NOK/NA

- (***)
- Trace on USB Stick
 - Database (Genius.mdb)
 - Screenshot from Application settings
 - System picture

☐	☒	☐
☐	☒	☐
☐	☒	☐
☐	☒	☐

On Customer Site

Parts replaced during Preventive Maintenance :

1 –

2 -

Parts suggested to replace during the next Maintenance :

1 –

3 -

2 -

4 -

Part need to be replaced as soon as possible :

1 -

4 -

2 -

5 –

On Customer Site

Notes
