

On Customer Site

Visit Report

Reference :

Commande BSTe France : Offre N SER220420, BSTDEChaJ		Call : E1173	
Customer :	Devevey Imprimerie	System :	DS 330 HR1
Customer Contact :	M. David Fransioli	SN :	42.1732
Customer Order number :	CDE CLIENT BPA du 21042022	Machine Nickname :	Aniflo 3

Visit Purpose :

Mechanical Preparation	☐	Installation	☐	Start-up	☐
Maintenance	☒	Under Contract	☐	Out of Contract	☒
Troubleshoot	☒	Under Warranty	☐	Out of Warranty	☐
Instruction	☐ Yes				
	☒ No				

	11/05/2022					
Travel To	1.75					
Start Time	10h40					
Lunch Time	0.5					
End Time	13h00					
Travel From	0					

Details	Maintenance Préventive. Caméra recentrée et mise à niveau pour contact avec Roller Backing Bar. Mise à jour du software.
---------	---

Purpose of the visit completed : Yes ☒ No ☐
 Need a new visit : Yes ☐ No ☒

On Customer Site

Customer details for NYQUIST Systems

Customer name and place : [Devevey Imprimerie / 23 rue Champollion, 21200 Beaune - France](#)

Contact person at customer : [M. David Fransioli \(Chef d'Atelier\)](#)

Customer Mail & Mobile/Landline : dfransioli@imprimerie-devevey.com / +33 6 45 30 58 75

System Type : [DS 330 HR1 / M2051C-0.1388](#)

SN : [42.1732](#)

Machine Manufacturer/Model/Nickname : [CODIMAG / VIVA 340 - N°V373 / Aniflo 3](#)

Date : [11/05/2022](#)

Name : [Arnaud Darcel](#)

Comments :

Signatures :

A handwritten signature in blue ink, appearing to be "Arnaud Darcel".

Arnaud Darcel 2022-05-16T17:12:10+02:00

BST eltromat FSE

Customer

On Customer Site

Prior to a Preventive Maintenance :

Check for system affecting modification reports and software releases.
 Check for optional light source.
 Check with customer about problems, or failure with the system.

1. Cleaning the optical parts :

OK/NOK/NA

- | | |
|---|---|
| - Mirror cleaned with ZEISS lens wipes. | ☒ ☐ ☐ |
| - Camera lens cleaned with ZEISS lens wipes. | ☒ ☐ ☐ |
| - Reflectors cleaned with soft cloth using iso propanol or alcohol. | ☒ ☐ ☐ |
| - Backing Bar cleaned with soft using iso propanol or alcohol. | ☒ ☐ ☐ |
| - Optionally acryl insert of backing bar replaced. | ☐ ☒ ☐ |

2. Check functioning of the LEDs :

OK/NOK/NA

- | | |
|---|---|
| - LEDs checked. | ☒ ☐ ☐ |
| - Brightness and uniformity of the image checked. | ☒ ☐ ☐ |

3. Replacement of the encoder wheel :

OK/NOK/NA

- | | |
|---|---|
| - Encoder wheel replaced and tightened | ☒ ☐ ☐ |
| - Spring replaced (if necessary) and spring force checked (ca. 1kg/10N) | ☒ ☐ ☐ |

4. Software update :

OK/NOK/NA

- | | |
|-----------------------------------|---|
| - Software Update (if necessary). | ☒ ☐ ☐ |
|-----------------------------------|---|

 Old SW version : [7.2.51.80](#)

 New SW version : [7.2.77.115](#)

On Customer Site

5. Final check of the running system :

OK/NOK/NA

- | | |
|--|---|
| - Stability of live image checked (without reference image). | ☒ ☐ ☐ |
| - Stripe alignment checked (Normal and reflective mode). | ☒ ☐ ☐ |
| - Registration checked. | ☒ ☐ ☐ |
| - Maximum speed checked. | ☒ ☐ ☐ |
| - Stable location of the EagleView camera checked. | ☐ ☐ ☒ |
| - Hard drive capacity checked. | ☒ ☐ ☐ |
| - Backup created and saved locally and/or on USB stick. | ☒ ☐ ☐ |

6. Backup :

OK/NOK/NA

- | | |
|--------------------------------------|---|
| - NYCAMConfig folder | ☒ ☐ ☐ |
| - NYCAMProg folder | ☒ ☐ ☐ |
| - WindowsImageBackup and/or Image | ☐ ☒ ☐ |
| - Application / Computer Screenshots | ☒ ☐ ☐ |

Parts replaced during Preventive Maintenance :

- | | |
|-------------------|-----|
| 1 – Encoder Wheel | 3 - |
| 2 - | 4 - |

Parts suggested to replace during the next Maintenance :

- | | |
|-----|-----|
| 1 – | 3 - |
| 2 – | 4 - |

Part need to be replaced as soon as possible :

- | | |
|-----|-----|
| 1 - | 4 - |
| 2 - | 5 - |

On Customer Site

Technical datas

Computer name : [TubeScan421732](#)

Total Physical Memory : [8 GB](#)

Free Space in C Drive (System) : [182 GB](#)

OS : [Windows 10 Pro / v1909](#)

Screen Resolution Touch : [1024x768](#)

Screen Resolution Full View : [1920x1080](#)

Computer Model : [OptiPlex 3080](#)

Date : [2021](#)

Remote Maintenance (Teamviewer)

IP address : [DHCP Auto](#)

Subnet mask :

Default gateway :

Preferred DNS server :

Alternate DNS server :

Teamviewer ID / Version : [1 000 685 483 / v12](#)

On Customer Site

Notes
