

BST Eltromat France SARL Impasse de la Noisette - CE402 F-91374 Verrières le Buisson Tél.: +33 1 69 20 07 41 Email: bstfrance@bst.group Web: https://www.bst.elexis.group/	SPS Médical 231726 M. Corentin Mathieu 5 Rue de Montigny - ZI 77120 Coulommiers France +33 1 64 75 60 05 corentin.mathieu@spsmedical.fr
---	---

Ticket number:	E2177
Customer order:	CDE CLIENT A267533
Machine customer name:	DCM 1
Origin BST France order:	234414
AR:	
Tiket type:	INSTALLATION
Assign to:	NguJ -> jean-baptiste.nguyen@bst.group
Ticket date:	2024/07/31
Material:	VIDEO_Tubescan_XL
Type:	TubeScan XL 1100 7200 / M2051dC
SN:WA:	ASO102968_50.2877
Installation date of material:	2024/04/05
Teamviewer:	1 679 478 337 / v15
PC model:	OptiPlex 3090
Original Application Version	v7.4.62.27984
Upgraded VERSION application during intervention	8.0.32.29966

1 day(s) of intervention calculation

2024 / 2024	Mon.23/09
Drive time	2
AM Start	08:30
AM End	
PM Start	16:30
PM End	12:30
Drive time	2

Start date of intervention	2024/09/23-08:30
End date of intervention	2024/09/23-12:30
Reason:	upgrade to version 8 for print report pro QO (qualification operationel)
Actions:	* installation version 8.0.32 for PDF report PRO (attached)
Solution:	* 3 bobines test pour QO (after 3 test, better is using expert sensitivities with sensitivities below): - Front light (50µs) and backlight (20µs) - Expert sensitibilities - Arrière plan au maximum (hazing defect - Varnish detection - lanes detection) - Structure: taille: 1.2x1.2 Sensibilité: 8 - profil sensibilité TEST enregistré. * UPS check and procedure (to use correctly UPS must use main switch of electical cabinet to switch off application and system) * stipe offset adjustment for kisspoints cameras
Remarks:	
Ticket status:	solved

Comment(s)

(If fields are not visible please open PDF file with Google chrome or Microsoft edge navigator or update your navigator)

Customer signature:

Name:

Date :


23/09/2024 16:29

BS

T

eltromat FRANCE signature:

Name:

Date :


23/09/2024 16:22

ATTACHED CALL'S FILE(S)

Offre_240711-0155.pdf			CDE CLIENT A267533.pdf			REPORT_26ECHA4658.TEST2-1_2024-09-23-13-53.pdf		

ACCEPTANCE CERTIFICATE / CERTIFICAT D'ACCEPTANCE

BST Eltromat France SARL Impasse de la Noisette - CE402 F-91374 Verrières le Buisson Tél.: +33 1 69 20 07 41 Email: bstfrance@bst.group Web: https://www.bst.elxis.group/		SPS Médical 231726 M. Corentin Mathieu 5 Rue de Montigny - ZI 77120 Coulommiers France +33 1 64 75 60 05 corentin.mathieu@spsmedical.fr	
Ticket number:		E2177	
Customer order:		CDE CLIENT A267533	
Machine customer name:		DCM 1	
Origin BST France order:		234414	
AR:			
Tiket type:		INSTALLATION	
Assign to:		NguJ -> jean-baptiste.nguyen@bst.group	
Ticket date:		2024/07/31	
Material:		VIDEO_Tubescan_XL	
Type:		TubeScan XL 1100 7200 / M2051dC	
SN:WA:		ASO102968_50.2877	
Installation date of material:		2024/04/05	

ACCEPTANCE CERTIFICATE: We confirm the acceptance of system VIDEO_Tubescan_XL with serial number ASO102968_50.2877 installed the 2024/04/05 following parts list CERTICAT D'ACCEPTATION: Nous confirmons l'acceptation du système VIDEO_Tubescan_XL avec le numéro de série ASO102968_50.2877 installé le 2024/04/05 suivant la liste matériel de l'AR <i>Service instructions had been given by our engineer to following persons:</i> Les instructions de service ont été donné par notre ingénieur aux personnes suivantes:

Comment(s)
(If fields are not visible please open PDF file with Google chrome or Microsoft edge nagivator or update your navigator)

--

Customer signature:	BST eltromat FRANCE signature:
Name: Corentin MATHIEU	Name: NGUYEN
Date : 23/09/2024	Date : 23/09/2024