

On Customer Site

## Visit Report

**Reference :**

|                                      |                               |                          |         |
|--------------------------------------|-------------------------------|--------------------------|---------|
| Commande BSTe France : CM1912025 / 2 |                               | Call / PM number : PM881 |         |
| Customer :                           | Atlantique Packaging Cotentin | System :                 | Apollo  |
| Customer Contact :                   | M. Cédric Fautrat             | SN :                     | 307617  |
| Customer Order number :              | CM1912025 / 2 signed          | Machine Nickname :       | Cerutti |

**Visit Purpose :**

|                        |                                        |                |                                     |                 |                          |
|------------------------|----------------------------------------|----------------|-------------------------------------|-----------------|--------------------------|
| Mechanical Preparation | <input type="checkbox"/>               | Installation   | <input type="checkbox"/>            | Start-up        | <input type="checkbox"/> |
| Maintenance            | <input checked="" type="checkbox"/>    | Under Contract | <input checked="" type="checkbox"/> | Out of Contract | <input type="checkbox"/> |
| Troubleshoot           | <input type="checkbox"/>               | Under Warranty | <input type="checkbox"/>            | Out of Warranty | <input type="checkbox"/> |
| Instruction            | <input type="checkbox"/> Yes           |                |                                     |                 |                          |
|                        | <input checked="" type="checkbox"/> No |                |                                     |                 |                          |

|             |            |  |  |  |  |  |
|-------------|------------|--|--|--|--|--|
|             | 26/05/2025 |  |  |  |  |  |
| Travel To   | 5.5        |  |  |  |  |  |
| Start Time  | 15h00      |  |  |  |  |  |
| Lunch Time  | 0          |  |  |  |  |  |
| End Time    | 16h30      |  |  |  |  |  |
| Travel From | 0          |  |  |  |  |  |

|         |                                                                                                                                                    |
|---------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| Details | Maintenance Préventive du système d'inspection Apollo sur presse Cerutti. Archivage. Nettoyage des optiques et calibration. Ajustement Kiss Point. |
|---------|----------------------------------------------------------------------------------------------------------------------------------------------------|

Purpose of the visit completed :      Yes ☒      No ☐

Need a new visit :      Yes ☐      No ☒

On Customer Site

---

## Maintenance Checklist for AVT Systems

---

Customer name and place : [CPC Cotentin / Chemin de la Canurie, 50250 La Haye-du-Puits](#)

Contact person at customer / Title : [M. Cédric Fautrat \(Technicien de Maintenance\)](#)

Customer Mail : [maintenance-cotentin@atlantiquepackaging.com](mailto:maintenance-cotentin@atlantiquepackaging.com)

Mobile/Landline : [+33 2 33 07 33 11](#) / [+33 7 80 61 36 91](#)

System SN : [307617](#)

SOB SN : [95203644](#) – SOB3 AR LED P4 FUJITSU 16G WIN7 M.CAM V5.3.1.2

Machine Manufacturer/Model/Nickname : [Cerutti / R 980 / Cerutti](#)

Date : [26/05/2025](#)

Name : [Arnaud Darcel](#)

Comments :

**Signatures :**



28-May-25 11:16 AM

BST eltromat FSE



28-May-25 11:16 AM

Customer

On Customer Site

## Prior to a Preventive Maintenance :

Check for system affecting modification reports and software releases.

Check for optional light source.

Check with customer about problems, or failure with the system.

### 1. Cleaning the optical parts :

OK/NOK/NA

- |                                                                     |                                                                                       |
|---------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| - Mirror cleaned with ZEISS lens wipes.                             | <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> |
| - Camera lens cleaned with ZEISS lens wipes.                        | <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> |
| - Reflectors cleaned with soft cloth using iso propanol or alcohol. | <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> |
| - Back plate cleaned.                                               | <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> |
| - Computer filter cleaned/ <del>replaced</del>                      | <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> |

### 2. Camera calibration :

OK/NOK/NA

#### Camera 1 :

- |                          |                   |                                                                                       |
|--------------------------|-------------------|---------------------------------------------------------------------------------------|
| - Field of View / Period | 520.00 mm / 10.00 | <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> |
| - Zero LED calibration : | Zero Signal       | <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> |

#### Camera 2 :

- |                          |                   |                                                                                       |
|--------------------------|-------------------|---------------------------------------------------------------------------------------|
| - Field of View / Period | 519.88 mm / 10.00 | <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> |
| - LED calibration :      | Zero Signal       | <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> |

### 3. Check functioning of the Lamps :

OK/NOK/NA

- |                                                   |                                                                                       |
|---------------------------------------------------|---------------------------------------------------------------------------------------|
| - Lamps replacement. : Qty x0 (LED)               | <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> |
| - Brightness and uniformity of the image checked. | <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> |

### 4. Replacement of the encoder wheel :

OK/NOK/NA

- |                                                                         |                                                                                       |
|-------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| - Encoder wheel replaced and tightened                                  | <input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/> |
| - Spring replaced (if necessary) and spring force checked (ca. 1kg/10N) | <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> |

On Customer Site

## 5. Software update :

OK/NOK/NA

- Software Update (if necessary).

☐ ☒ ☐

Old SW version : 5.3.1.4

New SW version :

## 6. Final check of the running system :

OK/NOK/NA

- Stability of live image checked (without reference image).
- Stripe alignment checked (Normal and reflective mode).
- Registration checked.
- Maximum speed checked.
- Hard drive capacity checked.
- Backup created and saved locally and/or on USB stick.

☒ ☐ ☐
☒ ☐ ☐
☒ ☐ ☐
☒ ☐ ☐
☒ ☐ ☐
☐ ☒ ☐

## 7. Backup :

OK/NOK/NA

- BackupRestore
- Archive Printflow

☒ ☐ ☐
☒ ☐ ☐

## Parts replaced during Preventive Maintenance :

- |     |     |
|-----|-----|
| 1 – | 3 - |
| 2 - | 4 - |

## Parts suggested to replace during the next Maintenance :

- |                     |     |
|---------------------|-----|
| 1 - Computer Filter | 3 - |
| 2 -                 | 4 - |

## Part need to be replaced as soon as possible :

- |     |     |
|-----|-----|
| 1 - | 3 - |
| 2 - | 4 - |

*On Customer Site*

---

## Technical datas

---

Computer name : [COT-CERUTTILCCD](#)

Total Physical Memory : [16 GB](#)

Free Space in C Drive (System) : [29.7 / 50.1 GB](#)      Free Space in D Drive : [352 / 415 GB](#)

Free Space in F Drive (Backup) : [234 / 465 GB](#)

OS : [Windows 7 Embedded SP1 – v740](#)

Screen Resolution 1 : [1920x1200](#)

Computer : [95203644 – SOB3 AR LED P4 FUJITSU 16G WIN7 M.CAM V5.3.1.2](#)

Date : [Mar, 2016](#)

SN : [307617](#)

ACB Firmware : [33/32](#)

### **Remote Maintenance (Teamviewer)**

IP address : [10.50.21.23](#)

Subnet mask : [255.255.255.0](#)

Default gateway : [10.50.21.1](#)

Preferred DNS server : [8.8.8.8](#)

Alternate DNS server :

**Teamviewer ID / Version** : [978 044 639 / v15](#)

On Customer Site

## Notes

### 1 – Kiss Point

