

On Customer Site

Visit Report

Reference :

Commande BSTe France : CM2105039		Commande BSTe Int. : PM276	
Customer :	Etik Ouest (Soullans)	System :	TubeScan DS 250 CP
Customer Contact :	M. Sylvian Gandemer	SN :	34.577
Customer Order number :	CM2105039 Signé	Machine Nickname :	Vega

Visit Purpose :

Mechanical Preparation	☐	Installation	☐	Start-up	☐
Maintenance	☒	Under Contract	☒	Out of Contract	☐
Troubleshoot	☐	Under Warranty	☐	Out of Warranty	☐
Instruction	☐ Yes				
	☒ No				

	15/12/2021					
Travel To	0.5					
Start Time	9h00					
Lunch Time	0					
End Time	11h30					
Travel From	4.5					

Details	Maintenance Préventive du système TubeScan sur débobineuse Smag Vega suivant check list.
---------	--

Purpose of the visit completed : Yes ☒ No ☐

Need a new visit : Yes ☐ No ☒

On Customer Site

Maintenance Checklist for NYQUIST Systems

Available supporting documents :

- Maintenance instruction for Digital Strobe & EagleView systems
- Check list for maintenance

Customer name and place : [Etik Ouest / ZA, Route des Borgnières – 85300 - Soullans](#)

Contact person at customer : [M. Sylvain Gandemer](#)

Customer Mail & Mobile/Landline : sgandemer@etikouest.com / +33 2 51 49 17 27

System Type : [TubeScan DS 250 CP / 318x-0.1111](#)

SN : [34.577](#)

Machine Manufacturer/Model/Nickname : [SMAG / Vega / Vega](#)

Date : [15/12/2021](#)

Name : [Arnaud Darcel](#)

Comments :

Signatures :



Arnaud Darcel 2021-12-15T11:12:12+01:00

BST eltromat FSE



Sylvain Gandemer 2021-12-15T11:11:59+01:00

Customer

On Customer Site

Prior to a Preventive Maintenance :

Check for system affecting modification reports and software releases.

Check for optional light source.

Check with customer about problems, or failure with the system.

1. Cleaning the optical parts :

OK/NA

- Mirror cleaned with ZEISS lens wipes. ☒ ☐
- Camera lens cleaned with ZEISS lens wipes. ☒ ☐
- Reflectors cleaned with soft cloth using iso propanol or alcohol. ☒ ☐
- Backing Bar cleaned with soft using iso propanol or alcohol. ☒ ☐
- Optionally acryl insert of backing bar replaced. ☐ ☐

2. EagleView – Cleaning and lubricating the rail :

OK/NA

- Rail cleaned (EagleView only). ☐ ☒
- Rail lubricated with silicone oil (EagleView only). ☐ ☒
- Length of traverse checked (Calibrate run). ☐ ☒

3. Check functioning of the LEDs :

OK/NA

- LEDs checked. ☒ ☐
- Brightness and uniformity of the image checked. ☒ ☐
- UV light option ☐
- Contourlight option ☐
- Back Light option ☒

4. Replacement of the encoder wheel :

OK/NA

- Encoder wheel cleaned/~~replaced~~ and tightened ☒ ☐
- Spring replaced (if necessary) and spring force checked (ca. 1kg/10N) ☒ ☐

On Customer Site

5. Software update :

OK/NA

- Software Update (if necessary).

☐ ☐

Old SW version : 6.2.25.75

New SW version : 6.2.25.75

6. Final check of the running system :

OK/NA

- Stability of live image checked (without reference image).
- Stripe alignment checked (Normal and reflective mode).
- Registration checked.
- Maximum speed checked.
- Stable location of the EagleView camera checked.
- Hard drive capacity checked.
- Backup created and saved locally and/or on USB stick.

☒ ☐
☒ ☐
☒ ☐
☒ ☐
☐ ☒
☒ ☐
☒ ☐

7. Backup :

OK/NA

- NYCAMConfig folder
- NYCAMProg folder
- WindowsImageBackup and/or Image
- Application / Computer Screenshots

☒ ☐
☒ ☐
☒ ☐
☒ ☐

Parts replaced during Preventive Maintenance :

- | | |
|-----|-----|
| 1 - | 3 - |
| 2 - | 4 - |

Parts suggested to replace during the next Maintenance :

- | | |
|-----|-----|
| 1 - | 3 - |
| 2 - | 4 - |

Part need to be replaced as soon as possible :

- | | |
|-----|-----|
| 1 - | 3 - |
| 2 - | 4 - |

On Customer Site

Technical datas

Computer name : [TubeScan-PC](#)

Total Physical Memory : [8 GB](#)

Free Space in C Drive (System) : [405 GB](#)

OS : [Windows 10 Pro](#)

Screen Resolution Touch : [1024x768](#)

Screen Resolution Full View : [1680x1050](#)

Camera SN :

Computer Model : [Optiplex 7040](#)

Date : [2016](#)

Remote Maintenance (Teamviewer)

IP address : [DHCP Auto](#)

Subnet mask :

Default gateway :

Preferred DNS server :

Alternate DNS server :

Teamviewer ID / Version : [340 474 223 / v11](#)

On Customer Site

Notes
