

On Customer Site

Visit Report

Reference :

Commande BSTe France : Cm1904021		Commande BSTe Int. : PM316	
Customer :	Haas Etiquettes	System :	TubeScan DS 430 CP
Customer Contact :	Mme. Froger Céline	SN :	36.844
Customer Order number :	Cm1904021	Machine Nickname :	CR4 RADJOU

Visit Purpose :

Mechanical Preparation	☐	Installation	☐	Start-up	☐
Maintenance	☒	Under Contract	☒	Out of Contract	☐
Troubleshoot	☐	Under Warranty	☐	Out of Warranty	☐
Instruction	☐ Yes				
	☒ No				

	11/02/2022					
Travel To	0					
Start Time	12h30					
Lunch Time	0					
End Time	14h00					
Travel From	0					

Details	Maintenance avec mise a jour du system
---------	--

Purpose of the visit completed : Yes ☒ No ☐

Need a new visit : Yes ☐ No ☒

On Customer Site

Maintenance Checklist for NYQUIST Systems

Available supporting documents :

- Maintenance instruction for Digital Strobe & EagleView systems
- Check list for maintenance

Customer name and place : [Les etiquettes Haas 20 rue des 20 arpents 77210 Samoreau](#)

Contact person at customer : [Mme Froger Céline \(Responsible Qualité\)](#)

Customer Mail & Mobile/Landline : c.froger@inessens.fr 0164237149

System Type : [DS 430 CP](#)

SN : [36.845](#)

Machine Manufacturer/Model/Nickname : [CR4/RADJOU](#)

Date : [11/02/2022](#)

Name : [Richard Relin](#)

Comments :

Signatures :



CELINE FROGER2022-02-15T10:57:11+01:00



CELINE FROGER2022-02-11T16:42:10+01:00

BST eltromat FSE

Customer

On Customer Site

Prior to a Preventive Maintenance :

Check for system affecting modification reports and software releases.

Check for optional light source.

Check with customer about problems, or failure with the system.

1. Cleaning the optical parts :

OK/NOK/NA

- Mirror cleaned with ZEISS lens wipes. ☒ ☐ ☐
- Camera lens cleaned with ZEISS lens wipes. ☒ ☐ ☐
- Reflectors cleaned with soft cloth using iso propanol or alcohol. ☒ ☐ ☐
- Backing Bar cleaned with soft using iso propanol or alcohol. ☒ ☐ ☐
- Optionally acrylic insert of backing bar replaced. ☐ ☒ ☐

2. EagleView – Cleaning and lubricating the rail :

OK/NOK/NA

- Rail cleaned (EagleView only). ☐ ☐ ☒
- Rail lubricated with silicone oil (EagleView only). ☐ ☐ ☒
- Length of traverse checked (Calibrate run). ☐ ☐ ☒

3. Check functioning of the LEDs :

OK/NOK/NA

- LEDs checked. ☒ ☐ ☐
- Brightness and uniformity of the image checked. ☒ ☐ ☐

4. Replacement of the encoder wheel :

OK/NOK/NA

- Encoder wheel replaced and tightened ☐ ☒ ☐
- Spring replaced (if necessary) and spring force checked (ca. 1kg/10N) ☐ ☒ ☐

5. Software update :

OK/NOK/NA

- Software Update (if necessary). ☒ ☐ ☐

Old SW version : [7.2.50.79](#)

New SW version :

On Customer Site

6. Final check of the running system :

OK/NOK/NA

- | | |
|--|---|
| - Stability of live image checked (without reference image). | ☒ ☐ ☐ |
| - Stripe alignment checked (Normal and reflective mode). | ☒ ☐ ☐ |
| - Registration checked. | ☒ ☐ ☐ |
| - Maximum speed checked. | ☐ ☒ ☐ |
| - Stable location of the EagleView camera checked. | ☐ ☒ ☐ |
| - Hard drive capacity checked. | ☒ ☐ ☐ |
| - Backup created and saved locally and/or on USB stick. | ☒ ☐ ☐ |

7. Backup :

OK/NOK/NA

- | | |
|--------------------------------------|---|
| - NYCAMConfig folder | ☒ ☐ ☐ |
| - NYCAMProg folder | ☒ ☐ ☐ |
| - WindowsImageBackup and/or Image | ☐ ☒ ☐ |
| - Application / Computer Screenshots | ☐ ☒ ☐ |

Parts replaced during Preventive Maintenance :

- | | |
|-----|-----|
| 1 - | 3 - |
| 2 - | 4 - |

Parts suggested to replace during the next Maintenance :

- | | |
|-----|-----|
| 1 - | 3 - |
| 2 - | 4 - |

Part need to be replaced as soon as possible :

- | | |
|-----|-----|
| 1 - | 4 - |
| 2 - | 5 - |

On Customer Site

Technical datas

Computer name : [Tubescan36844](#)

Total Physical Memory : [8GB](#)

Free Space in C Drive (System) : [396GB](#)

OS : [WINDOWS 10 PRO](#)

Screen Resolution Touch : [1024X768](#)

Screen Resolution Full View : [1920X1080](#)

Computer Model : OPTIPLEX 3050

Date : [2018](#)

Remote Maintenance (Teamviewer)

IP address : DHCP

Subnet mask :

Default gateway :

Preferred DNS server :

Alternate DNS server :

Teamviewer ID / Version : [1 445 781 074 / v12](#)

On Customer Site

Notes
