

On Customer Site

Visit Report

Reference :

Commande BSTe France : CM1911023		Commande BSTe Int. : PM529	
Customer :	Adhex Technologies	System :	TubeScan DS 430 CP
Customer Contact :	M. Clément Cortot	SN :	34.453
Customer Order number :		Machine Nickname :	Racer.04

Visit Purpose :

Mechanical Preparation	☐	Installation	☐	Start-up	☐
Maintenance	☒	Under Contract	☒	Out of Contract	☐
Troubleshoot	☐	Under Warranty	☐	Out of Warranty	☐
Instruction	☐ Yes				
	☒ No				

	10/10/2023					
Travel To	0					
Start Time	10h30					
Lunch Time	0					
End Time	12h00					
Travel From	0					

Details	Maintenance Préventive du système TubeScan sur presse Prati Saturn Classic TE400.
---------	---

Purpose of the visit completed : Yes ☒ No ☐

Need a new visit : Yes ☐ No ☒

On Customer Site

Maintenance Checklist for NYQUIST Systems

Available supporting documents :

- Maintenance instruction for Digital Strobe & EagleView systems
- Check list for maintenance

Customer name and place : [Adhex Technologies / 44 Rue de Longvic – 21300 – Chenôve - France](#)

Contact person at customer : [M. Clément Cortot \(Ingénieur Méthodes Process\)](#)

Customer Mail & Mobile/Landline : c.cortot@adhex.com / +33 6 23 87 80 03

System Type : [DS 430 CP / 318x-0.1944](#)

SN : [34.453](#)

Machine Manufacturer/Model/Nickname : [Prati / Saturn Classic TE400/ Racer.04](#)

Date : [10/10/2023](#)


Name : [Arnaud Darcel](#)

Comments :

Signatures :



Arnaud Darcel 2023-10-10T12:03:17+02:00



Clément Cortot 2023-10-10T12:03:04+02:00

BST eltromat FSE

Customer

On Customer Site

Prior to a Preventive Maintenance :

Check for system affecting modification reports and software releases.

Check for optional light source.

Check with customer about problems, or failure with the system.

1. Cleaning the optical parts :

OK/NOK/NA

- Mirror cleaned with ZEISS lens wipes. ☒ ☐ ☐
- Camera lens cleaned with ZEISS lens wipes. ☒ ☐ ☐
- Reflectors cleaned with soft cloth using iso propanol or alcohol. ☒ ☐ ☐
- Backing Bar cleaned with soft using iso propanol or alcohol. ☒ ☐ ☐
- Optionally acrylic insert of backing bar replaced. ☒ ☐ ☐

2. Check functioning of the LEDs :

OK/NOK/NA

- LEDs checked : 6/6 ☒ ☐ ☐
 - o UV : 5/6 ☐ ☒ ☐
 - o Back Light : 3/3 ☒ ☐ ☐
- Brightness and uniformity of the image checked. ☒ ☐ ☐

3. Replacement of the encoder wheel :

OK/NOK/NA

- Encoder wheel replaced and tightened ☒ ☐ ☐
- Spring replaced (if necessary) and spring force checked (ca. 1kg/10N) ☐ ☒ ☐

4. Software update :

OK/NOK/NA

- Software Update (if necessary). ☒ ☐ ☐

Old SW version : 7.2.67.100

New SW version : 7.2.67.100

On Customer Site

5. Final check of the running system :

OK/NOK/NA

- | | |
|--|---|
| - Stability of live image checked (without reference image). | ☒ ☐ ☐ |
| - Stripe alignment checked (Normal and reflective mode). | ☒ ☐ ☐ |
| - Registration checked. | ☒ ☐ ☐ |
| - Maximum speed checked. | ☐ ☒ ☐ |
| - Stable location of the EagleView camera checked. | ☐ ☐ ☒ |
| - Hard drive capacity checked. | ☒ ☐ ☐ |
| - Backup created and saved locally and/or on USB stick. | ☒ ☐ ☐ |

6. Backup :

OK/NOK/NA

- | | |
|--------------------------------------|---|
| - NYCAMConfig folder | ☒ ☐ ☐ |
| - NYCAMProg folder | ☒ ☐ ☐ |
| - WindowsImageBackup and/or Image | ☒ ☐ ☐ |
| - Application / Computer Screenshots | ☐ ☒ ☐ |

Parts replaced during Preventive Maintenance :

1 -

2 -

Parts suggested to replace during the next Maintenance :

1 – 1/6 UV LED

2 – Encoder Wheel

Part need to be replaced as soon as possible :

1 -

2 -

On Customer Site

Technical datas

Computer name : [TubeScan34453](#)

Total Physical Memory : [8 GB](#)

Free Space in C Drive (System) : [390 GB](#)

OS : [Windows 10 Pro](#)

Screen Resolution Touch : [1024x768](#)

Screen Resolution Full View : [1680x1050](#)

Computer Model : [Optiplex 3040](#)

Date : [2016](#)

Remote Maintenance (Teamviewer)

IP address : [DHCP Auto](#)

Subnet mask :

Default gateway :

Preferred DNS server :

Alternate DNS server :

Teamviewer ID / Version : [511 246 153 / v15](#)

On Customer Site

Notes
