

On Customer Site

Visit Report

Reference :

Commande BSTe France : CM2310056		Call : PM558	
Customer :	SBE	System :	TubeScan DS 330 4K
Customer Contact :	M. Nicolas Robert	SN :	ASO042900_38.1105
Customer Order number :	CM2310056 - Signé	Machine Nickname :	MPS 6

Visit Purpose :

Mechanical Preparation	☐	Installation	☐	Start-up	☐
Maintenance	☒	Under Contract	☒	Out of Contract	☐
Troubleshoot	☐	Under Warranty	☐	Out of Warranty	☐
Instruction	☐ Yes				
	☒ No				

	09/11/2023					
Travel To	0					
Start Time	15h00					
Lunch Time	0					
End Time	17h30					
Travel From	0.5					

Details	Maintenance Préventive du système TubeScan sur presse MPS 6.
---------	--

Purpose of the visit completed : Yes ☒ No ☐

Need a new visit : Yes ☐ No ☒

On Customer Site

Maintenance Checklist for NYQUIST Systems

Available supporting documents :

- Maintenance instruction for Digital Strobe & EagleView systems
- Check list for maintenance

Customer name and place : [SBE / 13 rue Théodore Botrel – 35550 – Pipriac - France](#)

Contact person at customer : [M. Nicolas Robert \(Coordinateur Flexo\)](#)

Customer Mail & Mobile/Landline : atelier.flexo@sbe-etiquettes.fr / +33 2 99 34 37 49

System Type : [DS 330 4K / BF3-M2-0.0833](#)

SN : [ASO042900_38.1105](#)

Machine Manufacturer/Model/Nickname : [MPS/EC 330-6/MPS 6](#)

Date : [10/11/2023](#)

Name : [Arnaud Darcel](#)

Comments :

Signatures :



Arnaud Darcel 2023-11-10T10:46:46+01:00

BST eltromat FSE



Nicolas Robert 2023-11-10T10:46:31+01:00

Customer

On Customer Site

Prior to a Preventive Maintenance :

Check for system affecting modification reports and software releases.

Check for optional light source.

Check with customer about problems, or failure with the system.

1. Cleaning the optical parts :

OK/NOK/NA

- | | |
|---|---|
| - Mirror cleaned with ZEISS lens wipes. | ☒ ☐ ☐ |
| - Camera lens cleaned with ZEISS lens wipes. | ☒ ☐ ☐ |
| - Reflectors cleaned with soft cloth using iso propanol or alcohol. | ☒ ☐ ☐ |
| - Backing Bar cleaned with soft using iso propanol or alcohol. | ☒ ☐ ☐ |
| - Optionally acryl insert of backing bar replaced. | ☐ ☒ ☐ |

2. Check functioning of the LEDs :

OK/NOK/NA

- | | |
|---|---|
| - LEDs checked : 3/4 -- > 1 LED Board down | ☐ ☒ ☐ |
| o UV | ☐ ☐ ☒ |
| o Back Light | ☐ ☐ ☒ |
| o Contour Light : | ☐ ☐ ☒ |
| - Brightness and uniformity of the image checked. | ☒ ☐ ☐ |

3. Replacement of the encoder wheel :

OK/NOK/NA

- | | |
|---|---|
| - Encoder wheel replaced and tightened | ☒ ☐ ☐ |
| - Spring replaced (if necessary) and spring force checked (ca. 1kg/10N) | ☐ ☒ ☐ |

4. Software update :

OK/NOK/NA

- | | |
|-----------------------------------|---|
| - Software Update (if necessary). | ☐ ☒ ☐ |
|-----------------------------------|---|

Old SW version : [7.2.81.120](#)

New SW version : [7.2.81.120](#)

On Customer Site

5. Final check of the running system :

OK/NOK/NA

- | | |
|--|---|
| - Stability of live image checked (without reference image). | ☒ ☐ ☐ |
| - Stripe alignment checked (Normal and reflective mode). | ☒ ☐ ☐ |
| - Registration checked. | ☒ ☐ ☐ |
| - Maximum speed checked. | ☒ ☐ ☐ |
| - Stable location of the EagleView camera checked. | ☐ ☐ ☒ |
| - Hard drive capacity checked. | ☒ ☐ ☐ |
| - Backup created and saved locally and/or on USB stick. | ☒ ☐ ☐ |

6. Backup :

OK/NOK/NA

- | | |
|--------------------------------------|---|
| - NYCAMConfig folder | ☒ ☐ ☐ |
| - NYCAMProg folder | ☒ ☐ ☐ |
| - WindowsImageBackup and/or Image | ☐ ☒ ☐ |
| - Application / Computer Screenshots | ☒ ☐ ☐ |

Parts replaced during Preventive Maintenance :

1 -

2 -

Parts suggested to replace during the next Maintenance :

1 – [Encoder Wheel](#)

2 –

Part need to be replaced as soon as possible :

1 – [1 LED Board down \(3 LED on 5 are violet\)](#)

2 -

On Customer Site

Technical datas

Computer name : [38-1105-Tubescan4K](#)

Total Physical Memory : [16 GB](#)

Free Space in C Drive (System) : [181 GB](#)

OS : [Windows 10 Pro / 2018](#)

Screen Resolution Touch : [1024x768](#)

Screen Resolution Full View : [1600X900](#)

Computer Model : [OptiPlex 7090](#)

Date : [2019](#)

Remote Maintenance (Teamviewer)

IP address : [192.168.0.3](#)

Subnet mask : [255.255.255.0](#)

Default gateway : [192.168.0.75](#)

Preferred DNS server : [8.8.8.8](#)

Alternate DNS server :

Teamviewer ID / Version : [1 201 626 730 / v12](#)

On Customer Site

Notes
