

On Customer Site

Visit Report

Reference :

Commande BSTe France :		Commande BSTe Int. : PM441	
Customer :	Stickem	System :	TubeScan DS 430 4K
Customer Contact :	M. Jérôme Dufils	SN :	40.1230
Customer Order number :		Machine Nickname :	MPS 410

Visit Purpose :

Mechanical Preparation	☐	Installation	☐	Start-up	☐
Maintenance	☒	Under Contract	☐	Out of Contract	☐
Troubleshoot	☐	Under Warranty	☐	Out of Warranty	☐
Instruction	☐ Yes				
	☒ No				

	16/02/2023					
Travel To	0.5					
Start Time	8h30					
Lunch Time	1					
End Time	14h30					
Travel From	0					

Details	Maintenance Préventive du système TubeScan sur presse MPS410 suivant check list.
---------	--

Purpose of the visit completed : Yes ☒ No ☐

Need a new visit : Yes ☐ No ☒

On Customer Site

Maintenance Checklist for NYQUIST Systems

Available supporting documents :

- Maintenance instruction for Digital Strobe & EagleView systems
- Check list for maintenance

Customer name and place : Stickem / Z.A. La Briquetterie – 76160 – Saint-Jacques sur Darmétal - Franc

Contact person at customer : M. Jérôme Dufils (Responsable Maintenance)

Customer Mail & Mobile/Landline : jdufils@stickem.fr / +33 2 32 86 52 72

System Type : TubeScan DS 430 4K / BF3-M2-0.1111

SN : 40.1230

Machine Manufacturer/Model/Nickname : MPS / EC 410/8 / MPS 410

Date : 17/02/2023

Name : Arnaud Darcel

Comments :

Signatures :

17/02/23
 Arnaud Darcel

BST eltromat FSE

Customer

J DUFILS



On Customer Site

Prior to a Preventive Maintenance :

Check for system affecting modification reports and software releases.

Check for optional light source.

Check with customer about problems, or failure with the system.

1. Cleaning the optical parts :

OK/NA

- Mirror cleaned with ZEISS lens wipes. ☒ ☐
- Camera lens cleaned with ZEISS lens wipes. ☒ ☐
- Reflectors cleaned with soft cloth using iso propanol or alcohol. ☒ ☐
- Backing Bar cleaned with soft using iso propanol or alcohol. ☒ ☐
- Optionally acryl insert of backing bar replaced. ☐ ☒

2. EagleView – Cleaning and lubricating the rail :

OK/NA

- Rail cleaned (EagleView only). ☐ ☒
- Rail lubricated with silicone oil (EagleView only). ☐ ☒
- Length of traverse checked (Calibrate run). ☐ ☒

3. Check functioning of the LEDs :

OK/NA

- LEDs checked. ☒ ☐
- Brightness and uniformity of the image checked. ☒ ☐
- UV light option ☐
- Contourlight option ☐
- Back Light option ☐

4. Replacement of the encoder wheel :

OK/NA

- Encoder wheel cleaned/~~replaced~~ and tightened ☒ ☐
- Spring replaced (if necessary) and spring force checked (ca. 1kg/10N) ☒ ☐

On Customer Site
5. Software update :

OK/NA

- Software Update (if necessary).

☒ ☐

Old SW version : 7.2.36.59

New SW version : 7.2.36.59

6. Final check of the running system :

OK/NA

- Stability of live image checked (without reference image).
- Stripe alignment checked (Normal and reflective mode).
- Registration checked.
- Maximum speed checked.
- Stable location of the EagleView camera checked.
- Hard drive capacity checked.
- Backup created and saved locally and/or on USB stick.

☒ ☐
☒ ☐
☒ ☐
☒ ☐
☐ ☒
☒ ☐
☒ ☐
7. Backup :

OK/NA

- NYCAMConfig folder
- NYCAMProg folder
- WindowsImageBackup and/or Image
- Application / Computer Screenshots

☒ ☐
☒ ☐
☐ ☒
☒ ☐
Parts replaced during Preventive Maintenance :

- | | |
|-----|-----|
| 1 - | 3 - |
| 2 - | 4 - |

Parts suggested to replace during the next Maintenance :

- | | |
|---------------------|-----|
| 1 – 2 LED Bar 160mm | 3 - |
| 2 - | 4 - |

Part need to be replaced as soon as possible :

- | | |
|-----|-----|
| 1 - | 3 - |
| 2 - | 4 - |

On Customer Site

Technical datas

Computer name : TubeScan401230

Total Physical Memory : 16 GB

Free Space in C Drive (System) : 174 GB

OS : Windows 10 Pro

Screen Resolution Touch : 1024x768

Screen Resolution Full View : 1920x1080

Camera SN : FF003951

Computer Model : Optiplex 5060

Date : 2019

Remote Maintenance (Teamviewer)

IP address : DHCP Auto

Subnet mask :

Default gateway :

Preferred DNS server :

Alternate DNS server :

Teamviewer ID / Version : 1 537 343 803 / v12

On Customer Site

Notes
