

On Customer Site

Visit Report

Reference :

Commande BSTe France : SERV211005DT		Call / PM number : PM251	
Customer :	Soyaux Plastiques Complexage	System :	Argus Elite
Customer Contact :	M. Thomas Roger	SN :	301343
Customer Order number :	BPA 11102021	Machine Nickname :	F2

Visit Purpose :

Mechanical Preparation	☐	Installation	☐	Start-up	☐
Maintenance	☒	Under Contract	☐	Out of Contract	☒
Troubleshoot	☐	Under Warranty	☐	Out of Warranty	☐
Instruction	☐ Yes				
	☒ No				

	09 / 11 /2021					
Travel To	2					
Start Time	13h30					
Lunch Time	0					
End Time	18h00					
Travel From	0.5					

Details	Maintenance Préventive du système d'inspection sur presse Comexi F2. Archivage.
---------	---

Purpose of the visit completed : Yes ☒ No ☐

Need a new visit : Yes ☐ No ☒

On Customer Site

Maintenance Checklist for AVT Systems

Customer name and place : [Soyaux Plastiques Complexages / Z.I La Croix Blanche – 16800 – Soyaux](#)

Contact person at customer : [M. Thomas Roger \(Responsible Site\)](#)

Customer Mail & Mobile/Landline : t.roger@spcomplexages.fr / +33 5 45 38 37 11

SN : [301343](#)

Machine Manufacturer/Model/Nickname : [Comexi / F2 / F2](#)

Date : [10/11/2021](#)

Name : [Arnaud Darcel](#)

Comments :

Signatures :



Arnaud Darcel 2021-11-10T12:44:06+01:00

BST eltromat FSE



Julien Trocherie 2021-11-10T12:43:47+01:00

Customer

On Customer Site

Prior to a Preventive Maintenance :

Check for system affecting modification reports and software releases.

Check for optional light source.

Check with customer about problems, or failure with the system.

1. Cleaning the optical parts :

OK/NOK/NA

- Mirror cleaned wit ZEISS lens wipes. ☒☐☐
- Camera lens cleaned with ZEISS lens wipes. ☒☐☐
- Reflectors cleaned with soft cloth using iso propanol or alcohol. ☐☐☒
- Back plate cleaned. ☒☐☐
- Computer filter cleaned/~~replaced~~ ☒☐☐

2. Camera calibration :

OK/NOK/NA

- Field of View / Period 1443.10mm / 10.05 ☒☐☐
- Offset/Gain Calibration. 97/109/111 – 50/50/49 – 10/10/11 (White (LF)) ☒☐☐
- Zero LED calibration : Any/Zero/Dig 130/129/130 ☒☐☐

3. Check functioning of the Lamps :

OK/NOK/NA

- Lamps replacement. : Qty x0 ☐☒☐
- Brightness and uniformity of the image checked. ☒☐☐

4. Replacement of the encoder wheel :

OK/NOK/NA

- Encoder wheel replaced and tightened ☐☒☐
- Spring replaced (if necessary) and spring force checked (ca. 1kg/10N) ☒☐☐

5. Software update :

OK/NOK/NA

- Software Update (if necessary). ☐☒☐

Old SW version : 5.4.#21

New SW version : 5.4.#21

On Customer Site

6. Final check of the running system :

OK/NOK/NA

- Stability of live image checked (without reference image).
- Stripe alignment checked (Normal and reflective mode).
- Registration checked.
- Maximum speed checked.
- Hard drive capacity checked.
- Backup created and saved locally and/or on USB stick.

☒	☐	☐
☒	☐	☐
☒	☐	☐
☐	☒	☐
☒	☐	☐
☒	☐	☐

7. Backup :

OK/NOK/NA

- BackupRestore
- Archive Printflow

☒	☐	☐
☒	☐	☐

Parts replaced during Preventive Maintenance :

- | | |
|-----|-----|
| 1 - | 3 - |
| 2 - | 4 - |

Parts suggested to replace during the next Maintenance :

- | | |
|--|-----|
| 1 - Lamps 23720006 Qty 4 | 3 - |
| 2 - Encoder Wheel | 4 - |

Part need to be replaced as soon as possible :

- | | |
|-----|-----|
| 1 - | 3 - |
| 2 - | 4 - |

On Customer Site

Technical datas

Computer name : [AVT-ELITE-F2](#)

Total Physical Memory : [16 GB](#)

Free Space in C Drive (System) : [13.5 GB](#)

Free Space in D Drive : [373 GB](#)

OS : [Windows 7 Embedded SP1 – v740](#)

Screen Resolution 1 : [1920x1080](#)

Screen Resolution 1 : [1920x1080](#)

Computer Model : [95203529 / X79SI](#)

Date : [Jun, 2013](#)

ACB Firmware : [31/31](#)

Remote Maintenance (Teamviewer)

IP address : [DHCP Automatic](#)

Subnet mask :

Default gateway :

Preferred DNS server :

Alternate DNS server :

Teamviewer ID / Version : [/ v12](#)

On Customer Site

Notes

