

On Customer Site

Visit Report

Reference :

Commande BSTe France : SERV201005DT		Call / PM number : PM170	
Customer :	Soyaux Plastiques Complexage	System :	Inspection System
Customer Contact :	M. Thomas Roger	SN :	201647
Customer Order number :		Machine Nickname :	FW1508

Visit Purpose :

Mechanical Preparation	☐	Installation	☐	Start-up	☐
Maintenance	☒	Under Contract	☐	Out of Contract	☒
Troubleshoot	☐	Under Warranty	☐	Out of Warranty	☐
Instruction	☐ Yes				
	☒ No				

	20 / 11 /2020					
Travel To	0.5					
Start Time	8h00					
Lunch Time	0					
End Time	9h45					
Travel From	2.5					

Details	Maintenance Préventive du système d'inspection sur presse Comexi FW1508. Teamviewer mise à jour. Archivage.
---------	---

Purpose of the visit completed : Yes ☒ No ☐

Need a new visit : Yes ☐ No ☒

On Customer Site

Maintenance Checklist for NYQUIST Systems

Available supporting documents :

Customer name and place : [Soyaux Plastiques Complexages / Z.I La Croix Blanche – 16800 – Soyaux](#)

Contact person at customer : [M. Thomas Roger \(Responsible Site\)](#)

Customer Mail & Mobile/Landline : t.roger@spcomplexages.fr / +33 5 45 38 37 11

SN : [201647](#)

Machine Manufacturer/Model/Nickname : [Comexi / FW1508 / FW1508](#)

Date : [20/11/2020](#)

Name : [Arnaud Darcel + Richard Relin](#)

Comments :

Signatures :



Arnaud Darcel 2020-11-20T11:09:28+01:00

BST eltromat FSE



Julien Trocherie 2020-11-20T11:09:16+01:00

Customer

On Customer Site

Prior to a Preventive Maintenance :

Check for system affecting modification reports and software releases.

Check for optional light source.

Check with customer about problems, or failure with the system.

1. Cleaning the optical parts :

OK/NOK/NA

- Mirror cleaned wit ZEISS lens wipes. ☒ ☐ ☐
- Camera lens cleaned with ZEISS lens wipes. ☒ ☐ ☐
- Reflectors cleaned with soft cloth using iso propanol or alcohol. ☐ ☐ ☒
- Back plate cleaned. ☒ ☐ ☐
- Computer filter ~~cleaned~~/replaced ☒ ☐ ☐

2. Camera calibration :

OK/NOK/NA

- Field of View / Period ☐ ☐ ☒
- Offset/Gain Calibration. ☐ ☐ ☒
- Zero LED calibration : Anyspeed & Position ☐ ☐ ☒

3. Check functioning of the Lamps :

OK/NOK/NA

- Lamps replacement. : ☐ ☐ ☒
- Brightness and uniformity of the image checked. ☐ ☐ ☒

4. Replacement of the encoder wheel :

OK/NOK/NA

- Encoder wheel replaced and tightened ☐ ☐ ☒
- Spring replaced (if necessary) and spring force checked (ca. 1kg/10N) ☐ ☐ ☒

5. Software update :

OK/NOK/NA

- Software Update (if necessary). ☐ ☒ ☐

Old SW version : [2.7.1](#)

New SW version : [2.7.1](#)

On Customer Site

6. Final check of the running system :

OK/NOK/NA

- Stability of live image checked (without reference image).
- Stripe alignment checked (Normal and reflective mode).
- Registration checked.
- Maximum speed checked.
- Hard drive capacity checked.
- Backup created and saved locally and/or on USB stick.

☒	☐	☐
☒	☐	☐
☒	☐	☐
☐	☒	☐
☒	☐	☐
☒	☐	☐

7. Backup :

OK/NOK/NA

- BackupRestore
- Archive Printflow

☒	☐	☐
☒	☐	☐

Parts replaced during Preventive Maintenance :

- | | |
|-----------------------------|-----|
| 1 - Filters | 3 - |
| 2 - | 4 - |

Parts suggested to replace during the next Maintenance :

- | | |
|-----|-----|
| 1 - | 3 - |
| 2 - | 4 - |

Part need to be replaced as soon as possible :

- | | |
|-----|-----|
| 1 - | 3 - |
| 2 - | 4 - |

On Customer Site

Technical datas

Computer name : [AVT-PV-FW8](#)

Total Physical Memory : [1 GB](#)

Free Space in C Drive (System) : [4.59 GB](#)

Free Space in D Drive : [38.7 GB](#)

OS : [Microsoft Windows XP Professional 2002 – SP2](#)

Screen Resolution 1 : [1600x600](#)

Screen Resolution 1 : [1600x600](#)

Computer Model : [95203401 / IMBA-8650](#)

Date : [Aug, 2008](#)

ACB Firmware : [28/19](#)

Remote Maintenance (Teamviewer)

IP address : [DHCP Automatic](#)

Subnet mask :

Default gateway :

Preferred DNS server :

Alternate DNS server :

Teamviewer ID / Version : [1 009 260 133 / v12](#)

On Customer Site

Notes

- Ventilateur pupitre HS