

On Customer Site

Visit Report

Reference :

Commande BSTe France : CM1911023		Commande BSTe Int. : PM528	
Customer :	Adhex Technologies	System :	TubeScan DS 330 HR1
Customer Contact :	M. Clément Cortot	SN :	50.2467
Customer Order number :		Machine Nickname :	Racer.03

Visit Purpose :

Mechanical Preparation	☐	Installation	☐	Start-up	☐
Maintenance	☒	Under Contract	☒	Out of Contract	☐
Troubleshoot	☐	Under Warranty	☐	Out of Warranty	☐
Instruction	☐ Yes				
	☒ No				

	10/10/2023					
Travel To	0					
Start Time	13h00					
Lunch Time	1					
End Time	14h30					
Travel From	2					

Details	Maintenance Préventive du système TubeScan sur débobineuse Prati Racer.03.
---------	--

Purpose of the visit completed : Yes ☒ No ☐

Need a new visit : Yes ☐ No ☒

On Customer Site

Maintenance Checklist for NYQUIST Systems

Available supporting documents :

- Maintenance instruction for Digital Strobe & EagleView systems
- Check list for maintenance

Customer name and place : [Adhex Technologies / 44 Rue de Longvic – 21300 - Chenôve](#)

Contact person at customer : [M. Clément Cortot](#)

Customer Mail & Mobile/Landline : c.cortot@adhex.com / +33 3 80 54 74 15

System Type : [DS 330 HR1 / M2051dC 0.1388](#)

SN : [50.2467](#)

Machine Manufacturer/Model/Nickname : [Prati / FS330 / Racer.03](#)

Date : [13/10/2023](#)

Name : [Arnaud Darcel](#)

Comments :

Signatures :



Arnaud Darcel 2023-10-13T09:44:58+02:00

BST eltromat FSE



Clément Cortot 2023-10-13T09:44:45+02:00

Customer

On Customer Site

Prior to a Preventive Maintenance :

Check for system affecting modification reports and software releases.

Check for optional light source.

Check with customer about problems, or failure with the system.

1. Cleaning the optical parts :

OK/NOK/NA

- | | |
|---|---|
| - Mirror cleaned with ZEISS lens wipes. | ☒ ☐ ☐ |
| - Camera lens cleaned with ZEISS lens wipes. | ☒ ☐ ☐ |
| - Reflectors cleaned with soft cloth using iso propanol or alcohol. | ☒ ☐ ☐ |
| - Backing Bar cleaned with soft using iso propanol or alcohol. | ☒ ☐ ☐ |
| - Optionally acryl insert of backing bar replaced. | ☐ ☒ ☐ |

2. Check functioning of the LEDs :

OK/NOK/NA

- | | |
|---|---|
| - LEDs checked : 4/4 | ☒ ☐ ☐ |
| o UV : 4/4 | ☐ ☒ ☐ |
| o Contour Light : 2/2 | ☒ ☐ ☐ |
| - Brightness and uniformity of the image checked. | ☒ ☐ ☐ |

3. Replacement of the encoder wheel :

OK/NOK/NA

- | | |
|---|---|
| - Encoder wheel replaced and tightened | ☐ ☒ ☐ |
| - Spring replaced (if necessary) and spring force checked (ca. 1kg/10N) | ☐ ☒ ☐ |

4. Software update :

OK/NOK/NA

- | | |
|-----------------------------------|---|
| - Software Update (if necessary). | ☒ ☐ ☐ |
|-----------------------------------|---|

Old SW version : 7.4.40.107

New SW version : 7.4.40.107

On Customer Site

5. Final check of the running system :

OK/NOK/NA

- | | |
|--|---|
| - Stability of live image checked (without reference image). | ☒ ☐ ☐ |
| - Stripe alignment checked (Normal and reflective mode). | ☒ ☐ ☐ |
| - Registration checked. | ☒ ☐ ☐ |
| - Maximum speed checked. | ☐ ☒ ☐ |
| - Stable location of the EagleView camera checked. | ☐ ☐ ☒ |
| - Hard drive capacity checked. | ☒ ☐ ☐ |
| - Backup created and saved locally and/or on USB stick. | ☒ ☐ ☐ |

6. Backup :

OK/NOK/NA

- | | |
|--------------------------------------|---|
| - NYCAMConfig folder | ☒ ☐ ☐ |
| - NYCAMProg folder | ☒ ☐ ☐ |
| - WindowsImageBackup and/or Image | ☒ ☐ ☐ |
| - Application / Computer Screenshots | ☐ ☒ ☐ |

Parts replaced during Preventive Maintenance :

- 1 -
2 -

Parts suggested to replace during the next Maintenance :

- 1 -
2 -

Part need to be replaced as soon as possible :

- 1 -
2 -

On Customer Site

Technical datas

Computer name : [TubeScan522467](#)

Total Physical Memory : [16 GB](#)

Free Space in C Drive (System) : [133 GB](#)

OS : [Windows 10 Pro](#)

Screen Resolution Touch : [1024x768](#)

Screen Resolution Full View : [1920x1080](#)

Computer Model : [OptiPlex 3090](#)

Date : [2023](#)

Remote Maintenance (Teamviewer)

IP address : [DHCP Auto](#)

Subnet mask :

Default gateway :

Preferred DNS server :

Alternate DNS server :

Teamviewer ID / Version : [1 503 596 094 / v15](#)

On Customer Site

Notes
